SYNOLAC® 1035 X 60

GENERAL INDUSTRY

Product Application details	SYNOLAC [®] 1035 X 60 is a short oil alkyd resin based on tall oil. SYNOLAC [®] 1035 X 60 is recommended for general purpose stoving mechanical properties and acid catalysed lacquers	enamels, with good
Performance Benefits	 Excellent gloss Good balance of mechanical properties Excellent yellowing resistance Excellent pigment wetting 	
Polymer Type	Solventborne Alkyd	
Sales Specifications	Solid Content at 125°C, % (ISO 3251)	59 - 61
	Viscosity at 25°C, mPa.s (Brookfield SC4-25/13R, 6.6s-1) (ISO 3219)	6000 - 15000
	Colour, Gardner scale (ISO 4630)	7 max
	Acid value, mg KOH/g (ISO 2114)	15 max
Other Characteristics ¹	Volatile Flash point, °C (ISO 3679)	Xylene 25
	Density / Specific Gravity at 25°C, g/ml (ISO 2811)	1.0
	Type of fatty acid	Tall oil fatty acid
	Fatty Acid content, %	38
	Note: Acid value and/or Hydroxyl value quoted relative to solid resin	
	1 The data provided for these properties are typical values, intended only as guides, and should not be construed as sales specifications	
Formulation Guidelines	SOLUBILITY SYNOLAC [®] 1035 X 60 is soluble in aromatic hydrocarbons, esters, ketones, glycol ethers, partially soluble in terpenic solvents and alcohols and insoluble in aliphatic hydrocarbons. <u>COMPATIBILITY</u> SYNOLAC [®] 1035 X 60 is compatible with short alkyd drying resins, oil free resins, urea/formaldehyde resins, benzoguanamine resins and nitrocellulose resins. It is partially compatible with short alkyd non drying resins and melamine/formaldehyde resins and incompatible with cardura resins.	



Product Safety	Please refer to the corresponding Safety Data Sheet.
Storage &	SYNOLAC [®] 1035 X 60 should be stored indoors in the original, unopened and undamaged container, in a dry place at a temperature not exceeding 30°C. Exposure to direct sunlight should be avoided.
Handling	In the above mentioned storage conditions the shelf life of the resin will be 9 months from the shipping date

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Arkema expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

Arkema has implemented a Medical Policy regarding the use of Arkema products in medical devices applications that are in contact with the body or circulating bodily fluids (http://www.arkema.com/en/social-responsibility/responsible-product-management/medical-device-policy/index.html) Arkema has designated medical grades to be used for such medical device applications. Products that have not been designated as medical grades are not authorized by Arkema for use in medical device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in medical devices, including without limitation, permanent or temporary implantable devices, and customers' medical devices. In the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade

It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies). It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician.

Arkema Coating Resins

420, rue d'Estienne d'Orves

92705 Colombes Cedex - France arkema.com - arkemacoatingresins.com

